



**CGA V-7—2015**  
**STANDARD METHOD OF**  
**DETERMINING CYLINDER**  
**VALVE OUTLET**  
**CONNECTIONS FOR**  
**INDUSTRIAL GAS MIXTURES**

**SIXTH EDITION**

**PLEASE NOTE:**

The information contained in this document was obtained from sources believed to be reliable and is based on technical information and experience currently available from members of the Compressed Gas Association, Inc. and others. However, the Association or its members, jointly or severally, make no guarantee of the results and assume no liability or responsibility in connection with the information or suggestions herein contained. Moreover, it should not be assumed that every acceptable commodity grade, test or safety procedure or method, precaution, equipment or device is contained within, or that abnormal or unusual circumstances may not warrant or suggest further requirements or additional procedure.

This document is subject to periodic review, and users are cautioned to obtain the latest edition. The Association invites comments and suggestions for consideration. In connection with such review, any such comments or suggestions will be fully reviewed by the Association after giving the party, upon request, a reasonable opportunity to be heard. Proposed changes may be submitted via the Internet at our website, [www.cganet.com](http://www.cganet.com).

This document should not be confused with federal, state, provincial, or municipal specifications or regulations; insurance requirements; or national safety codes. While the Association recommends reference to or use of this document by government agencies and others, this document is purely voluntary and not binding unless adopted by reference in regulations.

A listing of all publications, audiovisual programs, safety and technical bulletins, and safety posters is available via the Internet at our website at [www.cganet.com](http://www.cganet.com). For more information contact CGA at Phone: 703-788-2700, ext. 799. E-mail: [customerservice@cganet.com](mailto:customerservice@cganet.com).

Work Item 14-024  
Cylinder Valve Committee

---

NOTE—Technical changes from the previous edition are underlined.

NOTE—Appendix A (Normative) is a requirement.

NOTE—Appendix B (Informative) is for information only.

SIXTH EDITION: 2015  
FIFTH EDITION: 2009  
FOURTH EDITION: 2003  
THIRD EDITION: 1987

© 2015 The Compressed Gas Association, Inc. All rights reserved.

All materials contained in this work are protected by United States and international copyright laws. No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical including photocopying, recording, or any information storage and retrieval system without permission in writing from The Compressed Gas Association, Inc. All requests for permission to reproduce material from this work should be directed to The Compressed Gas Association, Inc., 8484 Westpark Drive, Suite 220, McLean, VA 22102. You may not alter or remove any trademark, copyright or other notice from this work.

<b>Contents</b>	<b>Page</b>
1 Introduction.....	1
2 Scope and purpose .....	1
2.1 Scope .....	1
2.2 Purpose .....	2
3 Definitions.....	2
3.2 Technical definitions .....	2
4 Description of the method .....	2
4.1 General.....	2
4.2 FTSC code classification .....	3
5 Principles for valve outlet selection .....	3
5.1 General.....	3
5.2 Gas concentration .....	3
5.3 Gas purity .....	4
5.4 Radioactivity .....	4
5.5 Pressure .....	4
6 Relation of mixture component rating numbers to valve outlet connection .....	4
6.1 Assignment of mixture component rating numbers .....	4
6.2 Assignment of valve connection outlet by mixture component rating number.....	4
6.3 Exceptions .....	4
7 Procedure for selecting valve outlet connections when all mixture components are listed in Table 2 of CGA P-47 [2] .....	4
8 Procedure for selecting valve outlet connections when one or more of the mixture components are not listed in Table 2 of CGA P-47 [2] .....	5
9 Examples.....	5
9.1 100 ppm hydrogen in nitrogen.....	5
9.2 5% trimethylamine in sulfur hexafluoride.....	6
9.3 0.5% oxygen + 0.5% nitrogen in methane.....	6
9.4 Refrigerant 500 (73.8% dichlorodifluoromethane + 26.2% 1,1-difluoroethane) .....	7
9.5 12% ethylene oxide + 88% dichlorodifluoromethane .....	7
9.6 5% carbon dioxide in oxygen.....	7
9.7 5% carbon dioxide in nitrogen .....	8
9.8 5% oxygen in argon.....	8
9.9 1% argon + 21% oxygen + 78% nitrogen (to simulate pure air).....	8
9.10 1% monoethylamine + 5% methyldichloroarsine in nitrogen.....	9
9.11 1% hydrogen chloride + 1% lewisite in nitrogen.....	9
9.12 1% methane + 99% air .....	10
9.13 100 ppm phosphine in air .....	10
9.14 4% each of methane, propane, ethane, propylene, hydrogen + 5.5% oxygen in nitrogen.....	10
9.15 4% each of methane, propane, ethane, propylene, hydrogen sulfide + 1% oxygen in nitrogen .....	11
9.16 10 ppm hydrogen sulfide in air .....	11
9.17 10 ppm hydrogen sulfide in nitrogen .....	11
9.18 100 ppm hydrogen chloride in hydrogen .....	11
9.19 1% arsine in hydrogen.....	11
9.20 25 ppm hydrogen selenide in air .....	11
9.21 150 ppm ethylene oxide in air .....	12
10 References .....	15

**Tables**

Table 1—FTSC numerical code for gas classification ..... 12  
Table 2—Segregation criteria for oxidizing or flammable mixtures ..... 13  
Table 3—Gas rating for mixtures ..... 13  
Table 4—Mixture component rating numbers ..... 15  
Table 5—Valve connection outlets for mixture component rating numbers ..... 15

**Appendices**

Appendix A—Valve outlet connections for gas mixtures utilizing high integrity connections (Normative) ..... 16  
Appendix B—Selection flow diagram (Informative) ..... 17

## 1 Introduction

The Compressed Gas Association's (CGA) original standard on cylinder valve outlet connections was adopted by the American Standards Association and the Canadian Standards Association in 1949 as *the American National, Canadian, and Compressed Gas Association Standard for Compressed Gas Cylinder Valve Outlet and Inlet Connections*. This publication is revised periodically and published as CGA V-1, *Standard for Compressed Gas Cylinder Valve Outlet and Inlet Connections* [1].<sup>1</sup> CGA V-1 provides valve outlet connections for numerous pure gases but only includes a few mixtures that have a history of being commercially or medically important and for which standards were in demand [1].

In recent years, there has been a tremendous increase in the number of industrial, specialty, and semiconductor gas mixtures entering the commercial market, and the need to have some separation in the applicability of valve outlets to the thousands of gas mixtures is apparent. CGA undertook the development of a procedure for providing some safe separation of valve outlets for gas mixtures having similar properties.

It was recognized that it was physically impossible to establish a sufficient number of different valve outlets to provide a major separation for these thousands of gas mixtures. After much consideration, CGA concluded that a practical and reasonable separation could be achieved by selecting a limited number of existing connections and assigning these to mixtures having similar properties. This was intended to minimize the misconnection of gas mixtures whereby a serious hazard could occur.

CGA V-1 provides outlet connections in a logical and orderly manner [1]. The method for determining a cylinder valve outlet connection for various industrial gas mixtures is based on a four-digit numerical code assigned to each gas based on its fire potential, toxicity, state of the gas, and corrosiveness (FTSC). FTSC codes have been consolidated into CGA P-47, *Guidelines for FTSC Codes and Current Gas Listings* and as such, the application of this standard requires referencing CGA P-47 [2].

References in this standard to valve outlet connection numbers are those contained in the thirteenth edition of CGA V-1 [1].

Medical gases and medical gas mixtures are given special treatment because of their applications, which involve the care and critical handling of medical patients. For this reason, outlet connections for mixtures of medical gases are considered on a mixture-by-mixture basis and are not covered in this standard. They are covered in CGA V-7.1, *Standard Method of Determining Cylinder Valve Outlet Connections for Medical Gases* [3].

## 2 Scope and purpose

### 2.1 Scope

This standard applies to the selection of a suitable cylinder valve outlet connection for industrial, specialty, and semiconductor gas mixtures for pressures up to 3000 psi (20 680 kPa) at 70 °F (21.1 °C).<sup>2</sup> It applies to cylinders filled for individual use, cylinders filled individually for the purpose of assembling into a cylinder bundle, and for all cylinder bundle manifold outlet connections.

This standard does not apply to cylinders contained within an assembled cylinder bundle filled as one individual unit by use of the cylinder bundle manifold outlet connections. It also does not apply to medical gas mixtures (see CGA V-7.1) [3].

For the assignment of ultra high integrity service (UHIS) connections for mixtures, see Appendix A. Appendix A is reproduced with permission from International Organization for Standardization (ISO) 10692-1:2001, *Gas cylinders—Gas cylinder valve connections for use in the micro-electronics industry—Part 1: Outlet connections* [5].

---

<sup>1</sup> References are shown by the bracketed numbers and are listed in order of appearance in the reference section.

<sup>2</sup> kPa shall indicate gauge pressure unless otherwise noted as (kPa, abs) for absolute pressure or (kPa, differential) for differential pressure. All kPa values are rounded off per CGA P-11, *Metric Practice Guide for the Compressed Gas Industry* [4].